



Socket	Function	Interface Description			
CN4	10PIN MCU front panel socket	1:+5	2:GND	3:5VSB	4:GND
		5:IKIN2	6:NC	7:RXD	8:TXD
		9:PWR_S	10:GND		
CN5	Debug UART	1:RX	2:TX	3:GND	
BT1	Battery seat				
CN7	SATA1				
CN8	SATA0				
J11	10PIN without MCU front panel socket				
CN9	10PIN without MCU front panel socket	1:+3.3	2:GND	3:IR	4:Y2
		5:Y1	6:X2	7:Y3	8:X1
		9:ALARM	10:REC		
J6	SATA power socket	1:+5	2:GND	3:GND	4:+12
CN6	FAN power socket	1:+12	2:GND		
CN14	12V input				
CN13	2USB+RJ45				
J10	VGA				
CN11	USB expansion seat	1:+5	2:DM	3:DM	4:GND
J7	Audio seat	up: input	down: output		
J8	HDMI				
J9	CVBS interface (only models with CVBS support this interface)				
CN1(J2)	BNC Video input	Right	Right	Left	Left



		up:VIDEO1	down:VIDEO2	up:VIDEO3	down:VIDEO4
CN3(J3)	BNC Video input	Right up : VIDEO5	Right down:VIDEO6	Left up:VIDEO7	Left down: VIDEO8